

Atomic Layer Deposition (ALD) Coating for Permeation Half-Life Control of Ablator Capsules

20th TFMS 2012 Santa Fe, NM

M. Schoff, D. Steinman, A. Alberti*,
H. Huang, D. Haas, A. Nikroo
*Purdue University



Supported by General Atomics Internal R&D

Atomic Layer Deposition (ALD) shows promise as permeation barrier alternative


- **Need to add permeation barrier to target shells to confine fusion fuel from fill until shot**
 - GDP target shells leak too fast, ~5 minute D_2 half-life
- **Desire ~4-10 hour D_2 half-life**
 - Long enough to retain fuel until shell is shot, but short enough to fill by permeation
- **Aluminum and PVA have previously been used as permeation barriers**
 - Sputtered Al – large variation in measured half-life
 - PVA Drop Tower – only 5% yield, <900 μ m OD shells
- **Initial ALD results**
 - High yield, high throughput, more repeatable
 - Successfully demonstrated with all size shells, various materials, manufactured defects, 3-D features

Previous methods use aluminum and PVA as permeation barriers, but are far from ideal


- **Sputter aluminum on shells mounted on post or sitting on Gelpak**
 - Little control over H-L, due to pinholes/voids in metal coating
 - Unreliable with very large spread even within same batch
 - Opaque layer limits characterization of interior
- **Drop shells covered in liquid PVA down tower with heated walls to solidify layer**
 - Low yield ~5%
 - Thick and non-uniform ($3 \pm 1 \mu\text{m}$)
 - Small shells only ($\text{OD} < 900 \mu\text{m}$)



New Method: Atomic Layer Deposition (ALD) provides uniform, pinhole-free very thin coatings




Uniform Al_2O_3
Coated on Si Wafer




- **Grow one monolayer per cycle, ~0.1 nm**
 - Designed for thin films, typically <100 nm
 - Precursor gas bonds to surface only
 - Conforms to structures, high aspect ratios
- **Transparent Al_2O_3 process very robust**
 - Low coating temperature is ideal for plastics
 - Process does not damage shell

Shells are placed on Gelpak® in ALD chamber, leaving the contact spot uncoated


- **Conformal coating everywhere except where shell is in contact with Gelpak**
 - Contact spot area determined by Gelpak retention level (0,4,8), shell size, and shell weight
- **Using Gelpak 8 leaves potentially undesirable Gelpak still attached to shell in visible residue ring**



Optical





SEM





875 µm OD GDP Shell

Method 1: Deliberately use area of exposed GDP at contact spot to scale permeation from uncoated shell


- Permeation rate of D_2 through the Al_2O_3 layer \ll GDP shell wall
 - Thickness of Al_2O_3 ~ 35 nm
- Assume all gas permeates through exposed GDP at contact spot, then expect Half-life (inverse of permeation rate) to scale with inverse of exposed GDP area
 - Area defined by residue ring
- Higher order corrections to model
 - Exposed GDP area different from residue ring
 - Al_2O_3 layer semi-permeable



Gelpak 8
D 160 μm
875 μm OD




2xGelpak 8
D 230 μm
1640 μm OD



Method 2: Using a fixed contact area, vary the thickness to change the permeation rate



- Large range of thicknesses produce desired barrier
- More repeatable and fine control compared to sputtered Al
- 10 hour half-life max due to permeation through contact spot
 - Up to 50 hour half-lives achieved by flipping shell during coating, sealing contact spots



By varying exposed GDP area and Al₂O₃ thickness, we can achieve greater flexibility and control over barrier

Conformal ALD coatings are ideal for use on complex geometries and 3-D features

- **Transparent ALD coating conforms to surface, preserving features**
- **Example: successfully coated 8 μm deep x 30 μm wide trench**
 - 25 nm flipped coating (2x12.5 nm) resulted in 32 hr half-life w/ trench, 40 hr w/o
 - Sputtered permeation barrier was unsuccessful due to shadowing and other non-uniformities
- **Can be extended to other 3-D features and targets (not just shells)**
 - Up to 5000:1 aspect ratios in literature



875 μm OD
17 μm wall

ALD coatings have other attractive benefits

- **Able to coat on variety of materials**
 - Plastic, silicon, oxides, metals, carbon
- **Thin ALD coatings are amorphous, stronger and harder compared to bulk materials**
- **Al₂O₃ process is temperature independent**
 - Demonstrated 120 °C, 80 °C, literature down to room temp
 - Ideal for temp sensitive plastics
- **Other materials available**
 - Oxides (including conductive), nitrides, metals
 - Adaptable to include other materials

Future research aims to dial in desired half-life and for shells to be used in real shot experiment

- Acquire more data and statistics to further validate permeation barrier model
- Experiment with other ways of selecting exposed area/masking
- Investigate and eliminate residual ring when shell removed from Gelpak
- Study initial seeding behavior of Al_2O_3 using Quartz Crystal Microbalance (QCM) to further increase repeatability and understanding

