


Dielectrophoresis of Liquid Deuterium for IFE Target Filling



R. Q. Gram and D. R. Harding
Laboratory for Laser Energetics

T. B. Jones
Department of Electrical and
Computer Engineering
University of Rochester

20th Target Fabrication Meeting
Santa Fe, NM
20–24 May 2012

Summary

Foam shells have been filled using dielectrophoresis



- There is a need to fill IFE targets more quickly than by permeation
- Basic predictions of dielectrophoresis are confirmed for liquid D_2 using parallel vertical electrodes
- Two methods of dispensing a small volume of liquid D_2 from a larger reservoir are demonstrated
- A volume of liquid has been wicked into a foam shell




This is a first demonstration of dielectrophoretic behavior in a cryogenic liquid.

Acknowledgement





- **Kyle Kentsch**
- **Eric Pan**
- **Weiqiang Wang**
- **Mark Wittman**

***Surface Evolver*^{*} software accurately predicts the shape of the liquid surface between electrodes by minimizing surface energy**



Matches height and curvature
of upper left image




A prediction of dielectrophoresis is verified: the height of a liquid column between parallel vertical electrodes

- A dielectric liquid in an electric field E is governed by


$$\nabla p_\ell = -\frac{1}{2} E^2 \nabla \epsilon - \rho_\ell g \hat{z}$$

where p_ℓ is hydrostatic pressure in the liquid, ϵ is permittivity, ρ_ℓ is the density of liquid, and \hat{z} is the vertical unit vector




- For the hydrogens, $\theta = 0$ for contact with nearly all materials


The height of rise of a column of liquid D_2 between parallel plates is accurately predicted






Electrodes: glass coated with indium tin oxide
Width = 7.6 mm
Gap = 0.86 mm




Converging electrodes are used to dispense a volume of liquid from the larger bath by “bifurcation”




Liquid height as a function of voltage has a double-valued solution




Vertical electrodes lift the liquid D₂ column to horizontal electrodes, allowing for a volume of liquid to be dispensed




**Liquid D₂ is lifted and moved horizontally,
then a separate volume is dispensed
by de-powering the lifting electrodes**




**1.4 KV to all
four electrodes**




**1.6 KV to all
four electrodes**



**1.7 KV to all
four electrodes**




**1.9 KV to two
electrodes
on right**




**0.3 KV to two
electrodes
on right**

Volume is approximately 28 μ L as required by an IFE target.

The volume of liquid D₂ that is dispensed depends on the initial voltage




~23 μL
Initial voltage \simeq 1.6 kV




~12 μL
Initial voltage \simeq 1.5 kV

A foam shell is placed into the region between the electrodes




Liquid D₂ (14 μ L) is rapidly absorbed (<10 s) into a foam shell at 25 K


ITO-coated electrodes




(i) 3.2-mm-diam
0.1-gm/cc rf foam shell (160- μ m wall)
Liquid D₂ droplet




(ii) Liquid moving to the
electrode containing
foam shell




(iii) Liquid encapsulating
and infiltrating the
foam shell



(iv) Encapsulation
and infiltration continues...



(v) Liquid infiltrating
the foam wall



(vi) Liquid fully absorbed
in the foam wall, shell void
is not filled

Further work is needed




- **A filled foam shell needs to be coated while cold with a barrier against leakage**
- **Greater precision is needed in generating the desired volume**
- **The desired amount of liquid needs to be obtained inside the cavity of the shell**
- **Dielectrophoresis needs to be tried with DT**


The ability to dispense and move droplets of liquid cryogen provides another way for loading DT into shells



1. Form liquid DT into discrete droplets
2. Wick liquid into the foam shell




3. Condense Ne (Ar, Kr, Xe) as a barrier coating onto the foam




Transport electrostatically

Thermal gradient
20 K \rightarrow 18 K

4. Form ice layer – move through a thermal gradient (20 K \rightarrow 19.5 K) at 0.001 K/5 min



5. Inject target – Ne overcoat ablated during transit
Tailor Ne thickness to insulate the target



An electromechanical microfluidic scheme is proposed for the cryogenic aspects of forming targets.

Foam shells have been filled using dielectrophoresis



- There is a need to fill IFE targets more quickly than by permeation
- Basic predictions of dielectrophoresis are confirmed for liquid D_2 using parallel vertical electrodes
- Two methods of dispensing a small volume of liquid D_2 from a larger reservoir are demonstrated
- A volume of liquid has been wicked into a foam shell

This is a first demonstration of dielectrophoretic behavior in a cryogenic liquid.