

# HIGH RATE E-BEAM YBCO PROCESS ON TAPE

Jonathan Storer, Chris Sheehan, Igor Usov, David Reagor  
MST Division- Superconductivity Center  
Los Alamos National Laboratory  
Los Alamos, New Mexico 87545  
\$500k, 1.5 FTE


Jeong-uk Huh\*, Gertjan Koster, Gerd Fischer\*\*, R.H. Hammond, M.R. Beasley  
Geballe Laboratory for Advanced Materials  
Stanford University  
Stanford, CA 94305-4045  
\*AFOSR  
\*\* DOE support:\$ 36k

- Introduction - Storer
- Materials science – Stanford - *Hammond*
- Reel-to-Reel processing – LANL - *Storer*
- Compulsory slides - *Storer*
- Questions – *Storer/Hammond*



# Co-evaporation produces high $J_c$ films

1.0 MA/cm<sup>2</sup> (SF, 77K) 1.1 micron thickness



# Evaporation has high throughput potential for making thick films

**Multi-hundred kW systems evaporating kg/hour exist  
in industry.**

-

**Examples:**

**Turbine blades**

**Titanium Metal Matrix Composites**

# Most likely: least expensive raw materials



# Results at Stanford show that liquid facilitated growth results in rapid growth of YBCO.

- High  $J_c > 1 \text{ MA/cm}^2$
- Lower fall-off with thickness  $\rightarrow$  higher  $I_c$
- Thick film potential  $> 5 \text{ microns}$
- Wide area at high linear speed (throughput)
- Pure, least expensive feedstock

# Outline


- Goals: (AFOSR Sponsorship)
  - Phase stability of YBCO
  - Phase equilibrium of thin films, role of liquid Ba-Cu-O
  - Growth morphology
- Introduction
  - Tools
    - Evaporation facility
    - FTIR
    - XRD – Dome
- Example of FTIR
  - Determination of liquid  $\text{BaCu}_2\text{O}_3 \rightarrow (\text{s})\text{CuO} + (\text{s})\text{BaCuO}_3$  in pressure, temperature
  - Monitor YBCO formation



# Outline


- Example of Dome - XRD
  - Growth of precursor YBCO at 830°C as add O<sub>2</sub>
    - Reaction of CeO<sub>2</sub> and YBCO
    - Comparison of growth at three O<sub>2</sub> pressures
    - Growth of low temperature precursor YBCO as function of temperature at three fixed O<sub>2</sub> pressures
- Lessons learned in XRD – Dome
- Processing in evaporation chamber
  - In-situ with pause
  - Data: Jc ~ 1MA/cm<sup>2</sup>, XRD, R(T) on RABiTS
    - Jc(H,77) – compared with PLD on RABiTS
  - TEM – Lateral growth
- Substrate used: LAO crystals, RABiTS(AMSC), IBAD-MgO(LANL)

# YBCO stability diagram



region where YBCO is stable (P,T)


where liquid Ba-Cu-O transition;





# Phase Diagram

Expected phase diagram  
(Wong-Ng, Cook)




$T > T_{MELT}$  Ba-Cu-O

Proposed metastable Diagram  
Based on  $Y_2O_3$  - BaCuO<sub>x</sub>-123

Deposition composition:  
Used through out this work

Y:16, Ba:30, Cu:54



# Film growth method

## Electron-beam reactive co-evaporation


Composition control

laser AA: Y & Ba

chopping ion gauge: Cu


Deposition rate  
 $100 \sim 300 \text{ \AA/s}$

Deposition pressure  
 $5 \times 10^{-5} \text{ Torr}$



# Fourier Transform InfraRed set up

Used to monitor dielectric properties during and post deposition  
wave lengths 500 to 6000 $\text{cm}^{-1}$



# XRD Dome Experiments

Controlled Atmosphere XRD





XRD heating dome

Capable of taking XRD measurements while heating the sample under a certain environment

Great way to find the post-deposition Condition for YBCO



# Example of FTIR

Determination of liquid Ba-Cu-O decomposition:  $\text{BaCu}_2\text{O}_3 \rightarrow (\text{s})\text{CuO} + (\text{s})\text{BaCuO}_3$



Path 2 - No change till  $\sim 650^\circ\text{C}$ : supercool liquid  $\rightarrow$  Glass

# FTIR during and After YBCO Deposition




# Examples of XRD Taken in Dome

A. Time sequence of growth on RABiTS: /CeO<sub>2</sub>/YSZ/Y<sub>2</sub>O<sub>3</sub>/Ni(W)

Reaction: YBCO + CeO<sub>2</sub> → BaCeO<sub>3</sub> – Does this prevent Epitaxial growth?

Monitor YBCO (005) & CeO<sub>2</sub>




Conclusion: 123 has nucleated C-axis before CeO<sub>2</sub> decays





# Example of XRD Dome:

## B. Traces of temperature and pressure with the dome experiment:



## RABiTS Tape




Growth occurs within seconds at higher pressure



# Example of XRD Taken in Dome:

## C. Growth of low temperature precursor



Investigate where in  $P_{O_2}$ ,  $T$  growth occurs



- Samples made at 300°C in  $5 \times 10^{-5}$  Torr  $O_2$  on LAO
- Mount in dome heat to 650°C in Argon
- Heat in three  $P_{O_2}$



# Heating in 5% $\text{Po}_2$

Scan starts near 880°C



# Heating in 0.25% $\text{Po}_2$

Scan starts near 830°C





# Heating in 0.05% Po<sub>2</sub>

Omega 17.74400  
2Theta 35.00000

Phi 353.00  
Psi 0.14

X 0.00  
Y 0.00

Scan starts near 810°C



(103)

(005)



# Summary

Sample #	% O <sub>2</sub>	Rapid Growth Temp	Time for Growth	(005)/(103)
489A1	5	880°C	2 min	13
489A6	0.25	830°C	5 min	25
492A1	0.05	810°C	8 min	110

On LAO


## Conclusions:

- Majority of growth occurs near liquid line
- Rate of growth higher PO<sub>2</sub>, higher temperature
- (103) less at low growth rate, low temperature



# Lesson Learned in XRD Dome

RABiTS and IBAD-MgO-LMO




- Region 1
  - Slow growth
  - “Perfect” c-axis
  - Hard to get  $O_2$  in
  - No pinning  $\ll 1\text{MA/cm}^2$
- Region 2
  - Fast growth
  - New tech required to suppress (103)  $\rightarrow J_c \sim 1\text{MA/cm}^2$  ( $1.1\mu\text{m}$ )
- Region 3
  - Polycrystalline
  - Homogeneous nucleation
  - Very rapid growth  $< 1\text{sec}$


10000/T (K)



# Processing in Evaporation Chamber




- Deposit at  $5 \times 10^{-5}$  Torr  $O_2$ ,  $830^\circ\text{C}$
- Add  $O_2$  2mTorr and pause for seconds
  - Form “Glassy” state
- Add more  $O_2$
- Cool down in  $O_2$
- $300^\circ\text{C}$ , Atmosphere  $O_2$



# Processing in Evaporation Chamber (cont)

Sample 478A3 (1.1 $\mu$ m) – RABiTS (AMSC)



Note: Small(103), No a-axis, BaCeO<sub>3</sub> formed by reaction




# Feldmann: Measured and Compared

Jc: 1.1  $\mu\text{m}$   
0.4  $\mu\text{m}$  – thinned } Stanford

PLD/RABiTS - ORNL


478A3 - RABiTS

0.6 micron PLD/RABiTS  
Cantoni et al (ORNL)  
(intra-grain/single crystal)  
Jc(0T) = 4.2, 4.5 MA/cm<sup>2</sup>



J<sub>c</sub>: 1.1μm  
0.4μm – thinned } Stanford



MOD – Kim et al (AMSC) **478A3** - RABiTS



# Processing in Evaporation Chamber

## (cont)

$J_c(H)$ : Feldmann-Wisc.  
Thinned 1.1  $\rightarrow$  0.4  $\mu\text{m}$ , Slight change




Note: No thickness dependence 1.1 – 0.4  $\mu\text{m}$

Suggests laminar growth grain structure, liquid phase involved

Comparable with 0.6  $\mu\text{m}$  PLD with  $J_c(0) = 4.2 \, \text{MA/cm}^2$

# Processing in Evaporation Chamber (cont)

Sample 491A2.5 - RABiTS






**Very good clean C-axis YBCO**



# Processing in Evaporation Chamber (cont)

491A2.5 - RABiTS











478A3

Terry Holesinger



# Conclusions

- FTIR has shown signature effects in the processing of YBCO that give important information on the phase stability and phase states during formation.
- The ex-situ XRD-Dome has shown:
  - Why  $\text{CeO}_2$  reaction with Ba is not a serious effect on the epi of YBCO.
  - Where in P, T the growth(assisted by liquid) occurs.
  - Types of growth in P, T region of stability diagram.
- Techniques developed to make MA/cm<sup>2</sup> on tape at 1.1um, which when etched, shown independence in thickness. This leads to a conclusion that lateral growth is the growth mode as shown by TEM.





# FOUR ISSUES

- Composition – 3 pools, different volatilities
- Oxygen – sufficient and compatible
- Temperature – controllable and uniform
- Epitaxy – compatible substrate

# Reel-to-Reel Coater at LANL



- 25 kW differentially-pumped electron gun
- Tunable Laser AA (TDLAA) vapor sensors (Y, Ba)
- HCL AA vapor sensor (Cu)
- Resistively heated tape
- Specialized software
- Microwave oxygen plasma applicator


Equipment donated by 3M Company

# Resistively heated tape



- Heat applied directly to tape.
- Pyrometer can view tape directly w/o hotter background.
- No burnout of quartz bulbs or plates to coat-up.
- Width & length scalable.
- Substrate thickness variations or coating conductivity can affect temperature.
- Emissivity problem same as IR heater.
- Arcing possible, conductive backside required.

**Current applied to tape through two water-cooled wheels and slip rings.**



# SUBSTRATES

**Both IBAD-MgO/CeO<sub>2</sub> (LANL) and RABiTS (AMSC) are being used in the LANL reel-to-reel process.**






# Microwave plasma to provide atomic oxygen




'06: characterize with AA and optimize

# Controls for three vapor sources



2-color pyrometer

AA laser beams




scanned electron beam




# Atomic Absorption: Robust, Accurate, Fast

Non-intrusive and windows do not coat-up.





Launch



Receive

# Tunable Diode Laser AA: yttrium and barium



Vapor rates



Note:  $^{137}\text{Ba}$  11%  $^{138}\text{Ba}$  72%

# Atomic absorption sensor - copper

**Lasers cannot reach the excessively strong ground state absorption line at 325 nm  
so use hollow cathode lamp (HCL)**




**Laser for copper is still a possibility!**

# RBS indicated non-uniform depth distribution of elements


**Non-uniform**  
**(Linear Source Geometry)**



**Uniform**  
**(Triangular Source Geometry)**



**Ce036b (ICP: 17.8%, 27.0%, 55.2%)**




**Ce046c (ICP: 20.9 at%, 26.5 at%, 52.6 at%)**  
**(RBS : 15.4 at%, 28.6 at%, 56.0 at%)**




## Source Geometry Modified


Programmable sweep Pierce-type electron gun also offers flexibility in source geometry.



**Linear Source Geometry**




**Triangular Source Geometry**




# LANL Co-Evaporation Composition in agreement with Stanford research

This composition maintained  $> \frac{1}{2}$  hour on moving tape



*Ex situ* composition determined by Inductively Coupled Plasma Emission Spectroscopy (ICP)


*in situ* deposition using  $O_1$  or  $O_3$ .



Max  $P_{\text{cham}} = 10 \text{ mT}$  ?



# YBCO on IBAD-MgO/CeO<sub>2</sub> has good texture



ce056c made at LANL, annealed at Stanford



# Criterion: Results

1.  $J_c$  of 1 MA/cm<sup>2</sup> 1.1 micron thick YBCO on RABiTS.
2. LANL has an operational, tape-based, computer-driven, co-evaporation system.
3. The FTIR tool has elucidated the details of the YBCO formation.
4. The XRD-Dome tool has elucidated details of the crystallization process.
5. The moving tape co-evaporation process has produced YBCO films on RABiTS and IBAD substrates.
6. Composition control at LANL has been demonstrated.
7. A Cu AA sensor was developed.



# Criterion: Performance

- ✓ **Goal: Install and improve equipment for electron beam co-evaporation at LANL.**
- ✓ **Goal: Operate equipment for electron beam co-evaporation with AA sensors, computer control and specialized software.**
- ✓ **Goal: Develop a evaporation (e-beam and thermal) deposition method capable of producing high Jc YBCO films.**
- ✓ **Goal: Produce YBCO films on RABiTS and IBAD.**
- ✓ **Goal: Develop a new atomic absorption (AA) tool for copper and demonstrate composition control ( $\pm 2$  at%) using computers for automation.**

# Criterion: Research Integration

- 1) There is a fruitful collaboration between Stanford and LANL that has improved the total program capabilities. Stanford is mapping out the pressure-temperature stability plot which is being used by LANL to demonstrate the process on moving tape.
- 2) LANL, through its CRADA with American Superconductor, has obtained RABiTS. It has been used by Stanford and LANL.
- 3) Both partners are also using LANL IBAD substrate.
- 4) The LANL co-evaporation program is co-located with LANL's PLD YBCO and IBAD operations. These experts are intimately involved with this program.
- 5) University of Wisconsin (Dr. Matt Feldman) made measurements of  $J_c$  on RABITS.
- 6) LANL's TEM is being used to elucidate growth patterns.
- 7) LANL's RBS has shown way to uniformity.
- 8) XRD and electrical measurements on Stanford samples is ongoing.
- 9) Patent filed.



# Criterion: 2006 Plans

- 1) Produce 1 meter of 1 cm tape with an Ic of 100 Amperes (SF, 75K).
- 2) Investigate post-annealing capitalizing on materials science work from Stanford. If promising, add annealing to the tape path.
- 3) Investigate oxygenation methods:
  - a) Activated oxygen using the microwave-powered oxygen plasma or ozone.
  - b) Explore higher ambient  $O_x$  pressure ~10 mT.
  - c) Install and operate an “oxygen pocket” device for moving tape.
  - d) Characterize and maximize  $O_1$  generation using AA.
- 4) Improve the tape thermometry through pyrometer improvements and calibration.
- 5) Stanford and LANL conduct sample exchange, visits and information in order to achieve these plans.

