





Opacity measurements at Z

Opacity Workshop
Los Alamos National Laboratory
May 5, 2005

without Fe



with Fe + Mg



J. E. Bailey (jebaile@sandia.gov)



Many people contribute to this work

G.A. Rochau, R.B. Campbell, G.A. Chandler, J. McKenney, and T.A. Mehlhorn

{Sandia National Laboratories, Albuquerque, New Mexico}

J.J. MacFarlane, P. Wang, I.E. Golovkin D. Haynes

{Prism Computational Sciences, Madison, Wisconsin}



R.C. Mancini

{University of Nevada, Reno, Nevada}

M. Bump, O. Garcia, J.M. Lucas, T.C. Moore


{K-Tech Corp., Albuquerque, New Mexico}

Z opacity experiments strengthen existing database and extend measurements beyond $T \sim 150$ eV





Laboratory opacity measurements at stellar interior conditions are not presently available



Solar model : J.N. Bahcall et al, Rev. Mod. Phys. 54, 767 (1982)



Mid-Z and high-Z opacities are important for many HEDP physics problems

- **ICF ablaters, e.g., Cu-doped Be or Ge-doped CH at T_e up to 300 eV**
- **Z-pinch radiation, e.g., tungsten at $T_e > 100$ eV**
- **Published laboratory opacity measurements at $T > 70$ eV are unavailable (non-existent?)**




Mid-Z elements pose a challenge for opacity calculations

- Charge state distribution (spectroscopic accuracy)
- What transitions must be included?
- What approximations for configuration and transition grouping?
- What line broadening?



Anatomy of an opacity experiment



Comparison of unattenuated and attenuated spectra determines transmission
 $T = \exp -\{\mu\rho x\}$



Desirable features of an opacity experiment

- **Sample spatial uniformity (thin, large lateral size, thick tamper)**
- **Minimal temporal variations during probe time (backlight short compared to heating x-ray variation)**
- **Steady state (long duration heating x-rays)**
- **Temperature and density measurements (large wavelength range to enable simultaneous low Z and high Z measurements)**

Characteristics of Z x-ray source can promote quality measurements





Possible experiment flaws can be evaluated from the scaling of transmission with sample thickness

Potential experiment problems:


- Sample may not be cartoon-like (pinholes, columnar structure)
- Sample composition or areal density may not match specifications (oxidation, contamination)
- Sample self emission may alter apparent transmission
- Conversion of film density to film exposure may be inaccurate
- Background subtraction incorrect
- Crystal defects may introduce artificial spectral features or mask actual features
- Lines may saturate


All of these problems cause transmission to deviate from expected scaling with thickness : $T_1 = T_2^{(x1/x2)}$

Opacity experiments can exploit the intense radiation provided by the Z accelerator



We have used two different opacity experiment configurations at Z





Each opacity experiment configuration offers advantages and disadvantages

Side-on:

- Multiple large samples exposed in a single experiment
- Many opportunities for ride alongs
- Temperature limited to ~ 50 eV or less

End-on:


- Single sample exposed in each experiment
- Relatively rare opportunities for ride alongs
- Temperatures above ~ 150 eV can be reached

Other configurations are feasible, but not yet demonstrated on Z

- External hohlraum (Springer et al., JQSRT 58, 927 (1997))
- Interior of dynamic hohlraum (Bailey et al, 2005)








Dynamic hohlraum radiation source is created by accelerating a tungsten plasma onto a low Z foam







The radiation source heats and backlights the sample



Opacity measurements were strongly suggested by Ti symmetry foil absorption spectra




This demonstrates:

- Foils reach interesting conditions
- Self backlight source is very bright



Ti absorption spectra are a rich opportunity for atomic physics, despite lack of optimization







Improvements:

- Mixtures to obtain T, r diagnosis
- Reduced thickness to improve uniformity
- Better crystal quality




L-shell Fe absorption features have been successfully recorded




One pair of Z experiments determines the Fe + Mg transmission



The sample conditions are diagnosed from Mg absorption spectra




Experiments with and without Fe enable determination of the Fe transmission



- The difference between z1363 & z1364 is the Fe+Mg transmission
- Assuming shot to shot reproducibility




The shot to shot reproducibility is good, if conditions are carefully controlled




- Both experiments used 10 μm CH | 0.3 μm Mg + 0.4 μm Fe | 10 μm CH sample
- No scaling was applied for this comparison
- Reproducibility is approximately 10% or better over this wavelength range

The dynamic hohlarum backlighter measures transmission over a very broad λ range






Transmission for two Fe thicknesses under similar T_e and n_e conditions has been measured






The transmission data scales with the thickness approximately as expected



- Significant portions of the spectrum scales with $\{T\}^x$, with x =thickness
- This supports method robustness - correct areal density, negligible self emission, correct film response, correct background subtraction
- Residual differences due to line saturation, possibly different T_e , n_e



The Fe L-shell spectrum exhibits a wealth of line absorption features




- Reproducing these features is a difficult test for any opacity model






PRISMSPECT calculations exhibit respectable agreement with Fe transmission




- The main features are well reproduced
- The calculated transmission has “windows” between the lines



The data enables tests of the calculated charge state distribution



Side-on opacity experiments use samples placed ~ 5 cm from the pinch




The ability to measure complex opacities is being developed using open M-shell bromine.



Goal for ride-alongs:

Use *FREE* radiation to measure opacities at

$\sim 20\text{-}70$ eV and $\sim 10^{-3} - 10^{-2}$ g/cc



Basic idea:


Pinch both heats and backlights sample

Na = thermometer; Br = test element

Develop method, then many elements can be measured





The drive temperature changes only by a modest amount over the z-pinch backlighter duration





time-integrated spectrum ~
peak power time-resolved spectrum

time-integrated spectrometers have
superior range and resolution






**The temperature and density are diagnosed with
roughly $\pm 10\%$ and $\pm 30\%$ uncertainties, respectively**







NaBr data can test opacity models




- SCO calculations by P. Arnault, T. Blenski, and G. Dejonghe (CEA France)
- J.E. Bailey et al., JQSRT 81, 31 (2003).

CH₂ foam opacity can be inferred by measuring heating of Mg foils placed behind different foam thicknesses.





Mg tracer heating behind different foam thicknesses discriminates between different CH₂ opacity models



This method is relatively indirect, but it can address a difficult to access regime



goals for future work

- **Model comparisons, feature identification**
- **Measure transmission with multiple Fe thickness on a single shot**
- **Extend to shorter and longer wavelengths**
- **Optimize tamping and sample design with benchmarked rad-hydro simulations**
- **Extend to higher densities and temperatures (ZR)**

Z opacity experiments strengthen existing database and extend measurements beyond $T \sim 150$ eV

