# Accelerated Coated Conductor Initiative: Progress Report

Los Alamos National Lab: Vladimir Matias


Oak Ridge National Lab: Fred List

Goal: Ensure US leadership in applications of HTS wire to electric power by providing new resources for accelerated research and development efforts.

- Industrial Overview Committee, Sept. 2000

### **US vis-à-vis International Efforts**

- Japan and Europe are making great strides in Coated Conductor development with help of greater government funding.
- US was losing the lead prior to ACCI.



100m tapes available from prototype production

Commercial tapes available in km lengths

Prototype transformers, generators, motors, cables

**Initiate market penetration** 

Source: LANL, ORNL, ISTEC






# Roles of Various Parties in Coated Conductor Development



(Applied research and commercialization)



National Labs have a prominent role in developing:

- A knowledge base for Coated Conductors (CC); in collaboration with universities
- A technology base for CC Processes; with collaboration with industry
- Applications demonstrations; in partnership with industry

ornl



### **LANL Effort**

Los Alamos National Lab Team for Accelerated Coated Conductor Initiative

### Coatings:

New Staff: Vladimir Matias, Brady Gibbons, Larry Bronisz Paul Arendt, Steve Foltyn, Eric Peterson, Randy Groves, Paul Dowden, Yates Coulter, Ray DePaula, Liliana Stan, Quanxi Jia

### Applications:


Jeff Willis, Alp Findikoglu, Steve Ashworth

Funding FY2001: \$2600K


\$700K operating costs and \$1900K capital costs



## Building on the Success of LANL Coated Conductors




#### **HTS Tape Materials System**



- Meter lengths of YBCO coated conductor have been fabricated by IBAD and PLD
- Over 120 A have been achieved in 1 cm wide meter long tapes
- Ion Beam Assisted
   Deposition of yttria-stabilized
   zirconia or magnesia is used
   as a template layer


### Ion Beam Assisted Deposition for Film Texturing

#### Non-single crystal substrate



## Pulsed Laser Deposition is a Versatile Approach for Oxide Film Deposition

 Pulsed Laser Deposition is used for growth of buffer layers and YBCO on heated tape







#### **Accelerated Coated Conductor Initiative at LANL**

- ACCI provides additional funding to accelerate the Coated Conductor research and development efforts
- STC is setting up a new facility dedicated to closer interaction with partners
- New facility will provide unique equipment and expertise for coated conductors
- Ability to evaluate alternate coated conductor approaches
- New facility will also provide a center for applications efforts and complete component design and fabrication



## New building at the Los Alamos Research Park



- Building finished in April 2001
- STC Tenant Improvements finished in July 2001
- Lab facilities to be finished in September 2001





Future plans
envision six
buildings in the
Industrial Research
Park



### STC Facilities at the Research Park



- 10,000 sq. ft. of space
- 7 new labs for Coated Conductor preparation and applications development
- 14 new offices for staff and partners
- Conference room and reception area






## Coated Conductor Labs at the Research Park

#### **Applications Key Themes:** Labs State-of-the-art labs Offices Process integration Measurements Reel-to-reel processing Lab In-situ diagnostics Applications research **Tape Preparation** User facility Lab **Pulsed Laser Deposition Lab** Ion Beam Assist **Deposition Lab Offices**



# Sequential Combinatorial Research from Continuous Tape Processing

 Continuous tape processing is ideal for exploring process parameters in a sequential way




- Our goal is to track positions on tape from one process step to the next and develop a matrix of experiments in a computer database
- Characterization needs to be done in the same way to track experiments
- Such combinatorial research provides for a highthroughput of experiments (100's of experiments in 1 reel)



### Tape preparation

- Coated conductors require prepared metal tapes with smooth surfaces
- New industrial-type equipment will process reels of metal tape by wet electrochemistry (etching, electropolishing, electroplating)













# Laser Scatterometer for Determining Surface Roughness

 Laser scatterometer from Optical Dimensions will be used *in-line* for instantaneous roughness measurements












# Proposed IBAD Chamber for Research Park Facility



- Continuous processing of longer lengths of tape (10 - 100 m)
- Capability for process integration
- Initial configuration with IBAD and e-beam evaporation
- In-situ monitoring and diagnostics




### **In-situ Monitoring and Diagnostics**

### A) Reflection High Energy Electron Diffraction (RHEED)


Grazing incidence e-beam diffraction: allows for *real-time* monitoring of the structure of the growing film.

# RHEED has proven useful for IBAD film growth


a-Si<sub>3</sub>N<sub>4</sub> substrate



after IBAD MgO




after homoepi MgO




RHEED provides information on:

- Structure of film during growth
- Texture development
- Optimum thickness (MgO)
- Out-of-plane tilt of film
- Grain size




### Parallel Scanning RHEED for Continuous IBAD



Problem: sample moves

Solution: track sample with e-beam

- Novel RHEED implementation: scanning RHEED in space and time
- By scanning the RHEED beam along the tape one obtains RHEED images at different stages of IBAD growth





### **In-situ Monitoring and Diagnostics**


### A) Reflection High Energy Electron Diffraction (RHEED)

### B) Ion scattering for surface analysis

Ion scattering is the most surface sensitive analytical tool. Real power of this tool is obtained in-situ where surfaces don't see any atmosphere.



# Time-of-Flight Ion Scattering and Recoil Spectroscopy




MSRI Mass Spectroscopy of Recoils

TOF-ISARS is useful for determining:

- top most layers
- residues
- contamination
- complete coverage
- diffusion of elements through layers
- · surface layer structure





Mass Spectroscopy Sensitivity ~few ppm



## **In-situ Monitoring and Diagnostics**

A) Reflection High Energy Electron Diffraction (RHEED)


B) Ion scattering for surface analysis

C) Atomic absorption monitoring for rate control

AA allows for *real-time in-process* monitoring of deposition rates



## Proposed PLD Chamber for Research Park Facility



Front view

- PLD: 200W Industrial Excimer Laser; allows for fast YBCO deposition (~15 meters/hour of 1 µm thick, 1 cm wide tape)
- Continuous deposition on longer lengths of tape (10 - 100 m)
- Capability for process integration (silver deposition)
- In-situ monitoring and diagnostics




### X-ray Diffraction Apparatus



- Bruker D8 Discover XRD
- 2D Position Sensitive Detector (GADDS)
- x,y stage with a minimum 10 µm spot size
- Future capability to include reel-to-reel sample transport









### XRD Texture Analysis: YBCO Microbridge

#### Bruker D8 Discover XRD with GADDS






- Microbridge
- 500 micron beam

Pole figures can be performed in ~10 minutes




### **Measurements Lab**

- Reel-to-reel low-temperature transport measurements (contact and non-contact; in magnetic fields up to 4 T)
- Data collection to be integrated with the sample preparation database




#### ac Loss Characterization

- Transport and magnetic field ac loss of YBCO tapes by electrical and calorimetric measurement techniques: I <~100 A, T=75-64 K, B=0-100 mT || and ⊥ to tape plane
- Investigate reduction
   of ac loss in ⊥ field by
   patterning tapes into strips



Electrical loss probe



Ashworth, Maley, Suenaga, Foltyn, Willis, J. Appl. Phys. 88, 2718 (2000)




#### ac Loss Characterization

- Investigate ac losses in YBCO cables using LANL ac loss three-phase cable calorimeter
- Allows measurement of ac losses for warm-dielectric design HTS

power cable

### **AC Loss Calorimeter**





### **FY2001 Performance and Results**

FY01 Goal: Begin staffing and equipment procurement for the IBAD/PLD facility in the Industrial Research Park

- ⇒ Space has been established for the new labs and offices; building construction is finished
- ⇒ Lab equipment procurement has begun; vacuum hardware and other equipment has been ordered
- ⇒ New staff has been hired (4 technical staff)
- ➡ Initial contacts with possible partners have been made; Argonne, Brookhaven and Oak Ridge Nat'l Labs are committed to collaborating at the Research Park



### **Technology Integration**

- Opportunity for new partnerships with industry, universities and national labs
- Minimize financial risk to companies
   Test concepts with small investment
- Co-location of industry with LANL now possible
- Basis for industrial collaborations can be User Facility Agreements and/or CRADA's
- New Industrial Internship program is now available
- Increased availability of Coated Conductor samples expected in the near future



### FY2002 Plans

- Set up the Coated Conductor Labs at the Research Park
- Demonstrate working continuous processes for coated conductors
- Demonstrate in-situ monitoring/diagnostics capability
- ac-loss measurements on long coated conductors
- Establish an open environment for research and a user facility where various parties can work together
- Establish meaningful partnerships with interested parties



### **Conclusions**

ACCI effort at Los Alamos is an aggressive program for Coated Conductor research and development with the goals for establishing the following:

- High-throughput sample preparation and characterization in continuous processing
- In-situ and real-time process diagnostics
- Applications effort using coated conductors
- Open environment for industrial partnerships
- User facility and training
- Educational opportunities for postdocs and students

