2004 DOE Peer Review Stanford *In-Situ* High-Rate YBCO Process Transfer to Metal Tapes and Process Scale Up

Presenters:

Hong - Ying ZhaiStanford University

Jonathan StorerLos Alamos National Laboratory

FY 2004 Funding: 100K





Stanford Coated Conductor Program:

•DOE – Hammond and Zhai (since 4/1/04)

- •Characterize and Scale-Up Stanford High-Rate Deposition Process and Transfer to LANL
- Apply to Metal Tapes Provided by LANL

•AFOSR Core Program – Hammond, Geballe and Koster

- •Basic Materials Science of YBCO Relevant to Coated Conductor Deposition
- •Exploration of YBCO 248 as an Alternative Coated Conductor Material
- •Development and Application of FTIR as an In-Situ Diagnostic for YBCO Thin Film Deposition

•AFOSR MURI – Beasley and Moler

•Development and Application of Scanning Probes for Coated Conductor Characterization – Large-Area, Sub-Micron Scanning Hall Probe and Scanning Tunneling Potentiometry





Outline of Talk – by Task


- Review of Stanford High-Rate Co-Evaporation Process
- Task I Develop Robust Process for Scale-Up at LANL (Report by Jonathan Storer, LANL)
 - o **Result:** More practical approach to Cu atomic absorption rate control dope Cu with RE. Rate control on RE. Avoids problem of strong atomic absorption of Cu.
- Task II Growth on LANL-IBAD Tapes (Report by Hong-Ying Zhai, Stanford)
 - o **Result:** Grew YBCO films on tape from 870° C 940° C. Characterized by XRD and resistivity. Lowering the substrate temperature shows an improvement in film quality.
 - o **Result:** Applied new FTIR characterization tool to tapes
 - Established directly temperature of film on tape during growth
 - Use FTIR reflectivity to monitor material state during deposition and processing.






Review of Present Stanford High-Rate Process

- Typical Deposition Conditions
 - ▶ Pressure: 10⁻⁵ Torr O₂
 - \triangleright Deposition $T_s \sim 900$ °C
- Evaporation Rate Monitoring
 - Y and Ba -- Laser **AA** (Atomic Absorption)
 - Cu -- Chopped Ion Gauge (ERM)
 - Cu absorption too strong to use AA*
 - * Storer (LANL) will discuss.






Deposition Process & Resulting Film Profile



deposition)




Results to Date on IBAD Tape



Fourier Transform Infrared spectroscopy (FTIR)

Principle of Operation for Temperature Measurement


- Measure radiance and reflectance as a function of ν or wavelength: 600-6000 cm-1~1.5-15 μm
- Reflectivity provides real time information of the thin film properties
- FTIR is valuable asset to coated conductor process both deposition as well as post anneal steps







FTIR in situ Observation of Film Growth



Ex situ X-ray Heating cycle

Investigate the *ex situ* heating cycle on the phase transitions in YBa₂Cu₃O₇ and Ba-Cu-O system on both IBAD tape and Single Crystal.

Ba-Cu-O system:
Epitaxial BaCuO₂+CuO
Layer by Layer
Deposited by 2-target
sequence by PLD

Ex situ X-ray system
Phillips Xpert
Dome Heat Stage (DHS)
280 mTorr O₂ + Ar
Temperature:
100-900° θ-2θ scan / 25 °C

It was found that the Ba-Cu-O epitaxial peak (~29°) appears repeatedly with temperature sweeping: A possible indication of liquid-solid transition

YBa₂Cu₃O₇ system

Study the stability of heating cycle in different temperature and $(0.28 \& 760 \text{ Torr}) O_2$ or $O_2 + \text{Ar}$. Found the information regarding to the phase transition of YBCO and information for co-evaporation or other low O_2 deposition system.





Summary

- 1. YBCO Deposited on IBAD Tape Substrate
 - Lower deposition temperature is the direction to go.
 - X-ray shows no reactions between YBCO/Buffer/Tape at 900°C.
- 2. We use Optical Infrared Reflectance (FTIR) to Monitor Phase Transitions in our Process in situ
- 3. Use X-ray Dome Heater Stage to Study Structure Transition ex situ.





Next

Jonathan will give the presentation on the work in LANL

Co-Evaporation of YBCO

Status of co-evaporation at LANL

Nd/Cu evaporation

Summary of LANL work



Opinion: Only reactive evaporation or a fast conversion process are commercial candidates.

Electron beam evaporation has deposited films at 1 μm/sec over an area of 750 cm² (15 cm x 50 cm)

An equivalent conversion process at 0.01 mm/sec has an area of 75000 cm² (10cm x 75 m)



Co-evaporation system is operational at LANL



From 3M Company, formerly used for BaF₂-Y-Cu co-evaporation with limited *in situ* YBCO runs.



Installation improved over previous




- •Skipping beam, differentially pumped electron gun
- •Tunable diode laser atomic absorption sensors
- •30 kW, 7.5 cm width.





LANL Co-evaporation Schematic



Atomic Absorption (AA) is feasible if

- 1. A ground state or low lying metastable state line in the range of an available tunable diode laser.
- 2. Oscillator strength is favorable for absorption measurement.



Picking the laser line

	Wavelength (nm vac)	Oscillator Str	Oscillator Strength		
Copper ground state					
	324.85	-0.062	Bad, Bad		
	327.49	-0.359	Bad, Bad		
Yttrium ground state					
	668.94	-2.000	Good, Good		
Yttrium metastable state					
	679.56	-1.820	Good, Good		
Neodymium ground state					
	692.58	-1.530	Good, Good		
	698.71	-1.940	Good, Good		
	733.66	-2.140	Good, Good		
Barium ground state					
	791.35	-2.000	Good, Good		

Ref: 1995 Atomic Line Data (R.L. Kurucz and B. Bell) Kurucz CD-ROM No. 23. Cambridge, Mass.: Smithsonian Astrophysical Observatory.




Several Solutions for copper rate sensor

- Chopped Ion Gage gas pressure sensitive but robust.
- HCL lamp AA (AtomicasTM) saturation?
- Sum frequency generation and group velocity delay shows promise.
- Nd/Cu congruent evaporation sense Nd as entire R.E. or tracer.



Copper and Neodymium Have Similar Vapor Pressures But close enough?





Composition Results (ICP)


	Nd	Ва	Cu	Cu/Nd	Note
Goal	17%	33%	50%	3	
First Run	2.73%	24.42%	72.86%	26.7	Graphite
Second Run	4.71%	24.10%	71.19%	15.1	Mo crucible
Third Run	15.58%	34.04%	54.38%	3.49	Mo crucible





Solution - Rod Feed

- Rod is Cu-RE mixture
- The solid rod beneath the melt provides material for steady state evaporation with a melt pool of the correct composition for a stoichiometric vapor plume
- Has been used at industrial scales (300 kW).
- Ti-6Al-4V evaporation shows that it can be done with great stability.





Summary

- Co-evaporation is operational at LANL.
- Several copper sensors are being explored. We have full confidence in a solution.
- IBAD template, PLD buffers, PLD YBCO, GADDS XRD, state-of-art measurement on site.
- Stanford and LANL have an excellent collaboration.
 - Reliable data on temperature profile during batch process will be applied to LANL tape process.
 - Exchange of ideas is fruitful and ongoing.



Performance FY 2004

1. Explorer the remained scale-up issues for CC & LANL

- More practical approach to Cu atomic absorption rate control dope Cu with RE.
 - (Jonathan Storer LANL)
- Explorer the Phase Formation FTIR.
- Study Rate/Liquid Layer X-ray DHS.

2. Apply Stanford High-R process on LANL IBAD tape

- Study the growth of YBCO films on tape with respect to the growth rate, deposition temperature, and post-deposition treatment.
- Characterized by XRD and R T.
- Performance of our film in terms of $J_c(\mathbf{B})$ (only measured on Xtl).
- Jc measurement system construction (tape).





Plan 2005

- 1. Continue Deposition of YBCO on IBAD Tape.
- 2. Make Optical Infrared Reflectance (FTIR) Available to Community as Desired.
- 3. Refine and Understand the Process on Tape
- 4. Modify the J_c & J_c(**B**) System for CC Tape Measurement.





Results 2004

- (Report by Jonathan Storer, LANL)
 - o More practical approach to Cu atomic absorption rate control dope Cu with RE. Rate control on RE. Avoids problem of strong atomic absorption of Cu.
- (Report by Hong-Ying Zhai, Stanford)
 - O Grew YBCO films on tape from 870° C 940° C. Characterized by XRD and resistivity. Lower substrate temperature resulting improved performance.
 - o Applied new FTIR characterization tool to tapes
 - Established directly temperature of film on tape during growth
 - Use FTIR reflectivity to monitor material state during deposition and processing.
 - O Using X-ray Heating Stage, study the phase transitions in YBa₂Cu₃O₇ and Ba-Cu-O system on both IBAD tape and Single Crystal.



Research Integration

- With LANL IBAD Tape:
 survives 900 °C / 2×10-5 O₂ condition.
- YBCO films on IBAD Tape Were Analyzed in LANL.
- Try Establishing in situ Approach for LANL Facility.
- Collaboration with ORNL on $J_c(\mathbf{B})$ measurements.
- Applications of FTIR in the CC Community.
- Willing to Help to the Program With FTIR Tools.





Team & Acknowledgments Team

Malcolm Beasley, Robert Hammond, Jeong-uk Huh, Gertjan Koster, Jung-hyuk Lee, Albert Chan, Arturas Vailionis, Hong-Ying Zhai

Acknowledgment

LANL: Jonathan Storer, Valdimir Matias

ORNL: Doug Lowndes, Hans Christen, Dave Christen
Parans Paranthaman, Patrick Martin, Fred List III, Dominic Lee
Amit Goyal, & Lan Zhang

Thanks



